



## DS812

# DOLPHIN FOAM CARTRIDGE DISPENSER – COUNTER MOUNTED

- > Counter mounted infrared foaming soap dispenser
- > Touch Free
- > Hidden dispenser helps prevent vandalism
- > 2 litre sealed cartridges – 6000 shots approx. (AL0742)
- > Adjustable soap shot size & air settings via remote – purchased separately (DB53)
- > Adjustable soap, air & range settings via advanced remote – purchased separately (DB52)
- > Powered by 3 pin 12v transformer. Draws maximum current of 0.5A at sensor activation
- > Suitable for Hand Sanitiser
- > The peristaltic pump allows the use of different soap viscosities, including antibacterial gels
- > Refill priming button
- > Power connections: soap dispenser female connects to male power source
- > Vent pipe level indicator provides visual alert to change the cartridge.
- > Compliant with WELL v2 2018 by International WELL Building Institute. W08 Handwashing, Part 2A and Doc M
- > Hand held shut-off connector used to connect new cartridge. Clicks in and out without exposing soap
- > Flexible pipe outlet hangs slightly below bottom edge of mirror
- > Stainless steel construction. Brushed satin and mirror polish finishes available; powder coating also available – contact us to enquire
- > 2 year guarantee
- 1000ml Bulk fill bottle available as alternative to sealed cartridge

<b>HEIGHT</b>	<b>500 MM</b>
<b>WIDTH</b>	<b>140 MM</b>
<b>PROJECTION</b>	<b>108 MM</b>

### PRODUCT CODES

- > **DS812** Counter mounted infrared foaming soap dispenser
- > **DS810** Behind mirror infrared foaming soap dispenser



DS812

## WHY CARTRIDGE?

---

### The Problem

- › Traditional bulk fill systems are at high risk of becoming contaminated and congealing due to exposure with environmental bacteria during the topping up process.
- › Congealing in soap can block filters, gauzes and pipework rendering dispensers inoperable and requiring replacement. Once contaminated it is extremely difficult to eliminate symptoms.

### The Solution

- › Sealed cartridges dramatically reduce the risk of bacterial contamination by removing the topping up process and the need to expose the soap.
- › A higher level of hygiene and reduced risk of congealing means the dispenser will maintain a higher efficiency/function for longer and require less maintenance. Connecting a new cartridge is quicker, cleaner and avoids spillages that can occur when decanting soap from one container to another

### Pack Contains

- › 1 x Behind Mirror Foam Cartridge Dispenser
- › 1 x Complimentary starter 2 litre refill cartridge – 6,000 shots approx (bought in pack of 4 ongoing)

### Compliance & Certification

- › The DS810 used in conjunction with compatible foam soap dispensers meets the requirements outlined in WELL v2 2018 by IWBI (International WELL building Institute)
- › Section Water; W08 Handwashing, Part 2A
- › WELL is a building standard with an aim to improve global health by transforming the spaces where people spend their lives. Research and evidence based.